

# How to Clean your slide:

## Major Detox

You will need:

- a washing up bowl full of warm water with a little washing up liquid in it.
  - a jug
  - a cloth (not fluffy)
  - some specialist slide clean
  - a small plastic water spray bottle (you can get them from boots or H&M)
  - plenty of space (gardens are good)
  - to be prepared to get wet
1. take the slide section and pour a jug of the water down one leg of the slide until it is nearly full
  2. work the slide up and down (not too quickly if you don't want to get soaked)
  3. pour away the dirty water and repeat several times (at least 4)
  4. take the cloth, and wipe down the inner legs (you can get long bendy brushes to clean the outer tube, but this isn't essential)
  5. put a small amount of slide cream on one inner leg at the very end, and work that one leg up, down, left & right in its outer leg
  6. repeat with the other leg
  7. spray a little water on to loosen the cream and work the whole slide up and down

## Quick fix slide clean:

1. wipe inner slide with a cloth
2. apply a little slide cream
3. loosen with the water spray

## Really Quick slide fix:

1. Spray inner slide with water

## Tuning Slide:

The Tuning Slide is at the top of the Trombone. It needs to move freely and is best lubricated with a little vaseline.

